




SNOWSYNC

Intercom Ski Goggles



User Guide

PRODUCT OVERVIEW



CHARGING

The Snowsync has an internal rechargeable battery. The battery must be fully charged prior to use. When the battery level drops below 10%, the red LED starts flashing intermittently twice. Your Snowsync cannot be used while charging.

Red light flashes --- Charging
Green light on --- Fully charging

A. Using the provided USB cable, connect the Snowsync_01 to the computer or laptop (USB port).

B. Using the provided USB cable, connect the Snowsync_01 to the AC Adapter (USB port).

POWER ON/OFF

TO POWER ON: Press and hold **Intercom Button** and **Multi-function Button** at the same time for 3 seconds to power on. When powered on, the indicator light is solid purple.

TO POWER OFF: Press and hold **Intercom Button** and **Multi-function Button** at the same time for 3 seconds to power off. The indicator light is off.

PAIR WITH YOUR PHONE

Press and hold **Multi-function Button** for 3 seconds in the power-on state and then release it to enter pairing mode, the voice prompt "Enter mobile phone pairing mode", and the indicator light flashes blue. The Bluetooth of the mobile phone is turned on to search for the Bluetooth of "Snowsync" for pairing, and after the pairing is successful, the voice prompt "Successful connection" indicator status: purple returns to solid on.

VOLUME CONTROL

VOLUME INCREASES: Short press the **Volume + Button** to increase the volume; When the maximum volume is reached, a prompt tone is played.

VOLUME DECREASES: Short press the **Volume - Button** to decrease the volume.

Chinese-English SWITCHING

In the power-on state, set the language switch through the APP, and after the switch is successful, the "语言设置成功/ Language Configured".

VOICE ASSISTANT

Double-tap the **Intercom Button** to wake up the voice assistant.


INTERCOM FUNCTION

1V1 QUICK INTERCOM:

1. In the power-on state, long press the **A Multi-function Button** of the first device for about 5 seconds until the blue light flashes quickly (Bluetooth passive search pairing), Chinese prompt: enter the intercom pairing mode.
2. In the power-on state, press and hold the **Intercom Button** of device B for 5 seconds until the blue light flashes quickly (Bluetooth actively search for pairing), Chinese prompt tone: intercom searching.
3. Put the two earphones close together, automatically complete the pairing mode, 2 devices at the same time Chinese voice prompt: voice intercom pairing successful. Function indicator prompts: The blue light stays on for 3 seconds, then returns to purple solid.

GROUP INTERCOM:

Including the host, a total of 6 devices for real-time intercom calls, assuming that device A is set up as the main device, device A is connected to the mobile phone, enter the APP, and in the APP group intercom functional area, pull friends into the group to realize group intercom




MAKING & ANSWERING CALLS

ANSWER A CALL: When Bluetooth is connected to the mobile phone, you can answer by pressing the **Multi-function Button** for a short time.

END A CALL: When answering a call, press the **Multi-function Button** briefly to hang up the call.

REJECT A CALL: Press and hold the **Multi-function Button** for 2 seconds to reject the call.



PLAYING MUSIC WITH BLUETOOTH DEVICES

TO PLAY OR PAUSE MUSIC: When Bluetooth is connected to the mobile phone, open the playback software, and press the **Multi-function Button** to play the mobile phone music. In playing mobile music, short press the function key once to pause/play music.

TO TRACK FORWARD OR BACK:

Music playback status, triple click the **Multi-function Button** to play the next song.
Music playback status, double-click the **Multi-function Button** to play the previous song.

RESET

Press the **Reset Button** with a pin, press for 2 seconds, and then restore to factory settings.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.